TECHNICAL DATA SHEET



■ INSTALLATION PROCESS



STEP1- Position and mark ground for the required location of the FLEXI Lite Slab.



STEP 2 - Prepare the ground.



STEP 3 - Drill the slab for insertion of pipework and insert the drainage bung.



STEP 4- Mark the area below the slab for the pipework so that you can lay the drainage pipes prior to finalising the slab install.



STEP 5 - Ensure that slab is level.



STEP 6- Measure the slab for the placement of the feet. This needs to match the pitch of the unit.



STEP7- Place the feet in position, and drill 9mm holes though the feet 50mm from each end.



STEP 8 - Attach all 4 base plates to the underside of the slab.



STEP 9 - Place the feet on the threads.



STEP 10 - Secure the feet with the nuts and washers, and position the spring nuts in the strut.



STEP 11 - The Flexi Lite Slab install is complete and ready for the unit



FLEXI FLEXI LITE SLAB & FOOT KIT

The DiversiTech International sales team are available to answer your questions or queries on this product. Our experts are waiting for your call +44 (0)115 900 5858 or if you prefer send an email to sales@diversitech.com or visit www.diversitech.global



Glaisdale Drive East Nottingham NG8 4LY United Kingdom