



CBR2-S, CBR2-M and CBR2-L Condensing Unit Support Brackets "Type 2"

INSTALLATION INSTRUCTIONS






TYPE 2 brackets INSTALLATION INSTRUCTIONS




CBR2-S, CBR2-M and CBR2-L



COMPONENTS

The DiversiTech International condensing unit support brackets are designed to support all leading brands of air conditioning condensing units and air source heat pumps, and have been independently tested and certified to the safe working loads, subject to the correct assembly and use of the product. DiversiTech International accepts no liability for failure of this product where it has been assembled incorrectly or has been used for a function outside it's intended application.



PARTS LIST							
Item	Qty	Part number	Description				
А	1	CBR2-L-1	Crossbar				
D	2	CBR2-L-2	Upright				
В	2	CBR2-L-3	Support arm				
K	10	M8 nut	ISO metric hexagon nuts				
J	14	M8 washer	M8 washer 25mm				

PARTS LIST								
Item	em Qty Part number Description							
М	4	M8 anti vibration washer	M8 anti vibration washer					
L	4	35mm sleeve	35mm sleeve					
Ν	2	M8 adj screw	M8 adj screw					
Н	2	M8 x 20mm	ISO metric screws					
G	4	M8 x 30mm	ISO metric screws					
Е	4	M8 x 50 wall bolts	ISO metric screws					

TYPE 2 brackets INSTALLATION INSTRUCTIONS




CBR2-S, CBR2-M and CBR2-L

INSTALLATION INSTRUCTIONS

- 1. Mark and drill the wall with four suitably sized holes at locations corresponding to the fixing holes provided in the bracket crossbar (A).
- 2. Fix the crossbar (A) to the wall using 4 x wall-fixing bolts (E).
- 3. Fit the support arms (B) to the uprights (D) using 4 x M8x55mm bolts (F), 8 x 20mm washers (I), 4 x M8 nuts (K) and 4 x bolt sleeves (L). The bolt sleeves are designed to prevent over-tightening of the bolts crushing the walls of the uprights and support arms.
- 4. Screw-in fully the wall-spacers (N) to the thread at the bottom rear of the uprights (B).
- 5. Attach the uprights (B) to the crossbar (A) using 2 x M8x20mm bolts (H), 4 x 20mm washers (I), 2 x M8 nuts (K). The horizontal distance between the these fixing positions should be the same as the distance between the feet of the condensing unit.
- 6. Fix the feet of the condensing unit to the support arms (B) using 4 x M8x30mm bolts (G), 8 x 25mm washers (J), 4 x M8 nuts (K) and 4 anti-vibration washers (M).
- 7. Adjust the wall-spacers (N) to ensure that the condensing unit is supported in a horizontal position.
- 8. Sea salts are very corrosive and affect both ferrous and non-ferrous metals. Coastal installations are particularly at risk as they are frequently exposed to sea salt solutions followed by dry periods, where this wet/dry cycle produces a very corrosive environment.

We strongly recommend that in such locations only our stainless steel brackets are installed.

BRACKET TYPES




TYPE 2 brackets INSTALLATION INSTRUCTIONS



CBR2-S, CBR2-M and CBR2-L

SPAN OF SUPPORT ARMS



	Width of unit		Depth of unit	
Model	Minimum (x)	Maximum (x)	Minimum (y)	Maximum (y)
CBR2-S condenser mounting bracket	50mm	660mm	55mm	295mm
CBR2-M condenser mounting bracket	245mm	800mm	155mm	395mm
CBR2-L condenser mounting bracket	300mm	940mm	195mm	435mm

GUIDANCE ON INSTALLATION

- 1. This product should be fitted by a competent installer of refrigeration air conditioning equipment or air source heat pump equipment
- 2. DiversiTech (Global) condensing unit support brackets are designed for use with all makes of condensing unit. Ensure that the bracket you have ordered is suitable for your condensing unit by referring to the safe working load and unit dimension tables.
- 3. The purpose of this product is to support refrigeration, equipment onto external walls.
- 4. Ensure wall or building fabric is capable of supporting the load.