

SOAK-1 - SOAKAWAY KIT FOR CONDENSING BOILERS



'Soak Up' Boiler condensate with our soakaway!

Where a suitable gravity drain is not available the soakaway can be used in conjunction with 10mm lime chippings.

Top and side inlet options compatible with the following pipe sizes: 22mm (3/4") overflow, 32mm (1-1/4") and 40mm (1-1/2").

FEATURES


- Universal inlet 22mm/32mm/40mm
- Side or top inlet
- Meets BS 6798 installation standards

THE PACKAGE


- Soakaway
- Inlet - 22mm / 32mm / 40mm
- Side or Top Inlet

RELATED PRODUCTS


- ASHP soakaway
- PVC coated insulation




1. Dig hole (min depth) 400mm x 300mm in diameter, at least 500mm from the wall




2. Fill the bottom of the hole with 100mm depth of lime chippings.



3. Insert the soakaway tube with the lower drain holes facing away from the property.



4. Fill the remaining part of the hole and tube with lime chippings



5. Feed the pipework either into the top or through the side of the soakaway.

Part code	Description	Height	Diameter	Inlet
SOAK-1	Soakaway Kit for Condensing Boilers	300mm	110mm	22mm / 32mm / 40mm

PUMPS SOAK-1

Soakaway Kit for Condensing Boilers

The DiversiTech International sales team are available to answer your questions or queries on this product. Our experts are waiting for your call +44 (0)115 900 5858 or if you prefer send an email to sales@diversitech.com or visit www.diversitech.global